

Birchwood Laboratories LLC 7900 Fuller Road Eden Prairie, MN 55344 Tel: 952 937 7931 Fax: 952 937 7979 www.birchwoodtechnologies.com

# **DRI-TOUCH® AMBER IRP2 Rust Preventive**

**Operating Instructions** 

## **PRODUCT DESCRIPTION**

DRI-TOUCH® AMBER IRP2 is a high grade, solvent-based corrosion preventive that forms a colorless, dry-to-touch protective film suitable for all metal surfaces. The liquid product has a pale amber color with a very mild odor and is easy and safe to work with. When applied to a metal surface, it rapidly penetrates recessed areas and displaces surface moisture, leaving a self-healing protective film that has high resistance to atmospheric humidity and corrosion. Protective film is self-healing but has a soft waxy consistency to resist draining off the part surface or wicking off into packaging materials. Contains no silicone. Harmless to plastics, paints, synthetic rubber.

#### **RECOMMENDED USES**

DRI-TOUCH® AMBER can be applied to wet or dry surfaces. Excellent as a corrosion preventive over black oxide or phosphate conversion coatings because it seals out corrosion and enhances the depth of color. Can also be used on uncoated metal surfaces for long term storage. Non-conductive film dries and lubricates without interfering with proper operation. Compatible with most lubricants, hydraulic oil, cutting oils.

#### APPLICATION

Dipping, brushing or conventional low pressure spray equipment. Dries in 10-30 minutes at ambient temperatures.

#### **PHYSICAL PROPERTIES**

Appearance Flash Point Film Thickness Coverage per gallon Pale, amber liquid. Mild solvent odor. 131° F T.O.C. Approximately 0.10 mil Approximately 1600 square feet per gallon

#### **PROTECTIVE PROPERTIES**

Humidity Test (ASTM D-1748) Salt Spray Test (ASTM B-117) Water Displacement Stain Test 600 hours minimum. 96-150 hours minimum. Meets Mil-C-16173#, Grade 3. Meets Mil-C-22235A

### **REMOVAL**

Solvent wash or heated alkaline detergent cleaners.

#### PACKAGING

5 gallon pails and 55 gallon non-returnable drums. Keep container closed during storage to prevent solvent loss.

*Before Using This Product* – Please Read, Understand and Follow all the Precautions shown on the Product Label and on the Safety Data Sheet.

The Safety Data Sheet can be found on our website: www.birchwoodtechnologies.com

Use Appropriate Warning Labels on any Container used to Store or Apply this Product.

<u>NOTE:</u> The information contained herein is provided in good faith and is believed to be correct as of the date below. However, Birchwood Laboratories LLC makes no representation as to the comprehensiveness or accuracy of the information. It is expected that individuals receiving the information will exercise their independent judgment in determining its appropriateness for a particular purpose. Accordingly, Birchwood Laboratories LLC will not be responsible for damages of any kind resulting from the use of or reliance upon such information.

DRI-TOUCH® AMBER IRP2 © Birchwood Laboratories LLC 07/2015 (Product Numbers 810450, 810451, 810458)