



Birchwood Laboratories LLC
7900 Fuller Road
Eden Prairie, MN 55344
Tel: 952 937 7931
Fax: 952 937 7979
www.birchwoodtechnologies.com

DRI-TOUCH™ RPL Replenisher Solvent Operating Instructions

PRODUCT DESCRIPTION

DRI-TOUCH™ RPL replenisher is a solvent-based corrosion-inhibiting solution, with less than 1% v/v aromatics, used to maintain proper concentration and solution balance of all Dri-Touch and Sheath solvent-based rust preventatives. Typically, in solvent-based solutions, the solvent evaporates readily. When the solvent evaporates, the corrosion-inhibiting solids concentration in solution goes up, and the Dri-Touch product becomes “thicker” or will leave a thicker residual film. In order to address this, we manufacture Dri-Touch RPL to serve as a diluting agent, in order to bring the solids concentration back to within recommended levels. Dri-Touch RPL replenishes the evaporated solvent, thereby reducing solids concentrations, along with enhancing and optimizing corrosion inhibition through the use of special additives.

APPLICATION

The addition of DRI-TOUCH™ RPL replenisher is determined after successful testing of the solids percentage is performed. A sample of your Dri-Touch or Sheath rust preventative can be tested either in-house, or at no charge by Birchwood Technologies. A method is available, upon request, detailing equipment needed and proper additions if you'd like to perform in-house testing.

PHYSICAL PROPERTIES

Specific Gravity (relative density)	0.78 g/mL (g/cm ³)
Flash Point T.O.C.	110°F
Color	Pale Amber (light brown)
Weight Per Gallon	6.5 lbs.

REMOVAL

Solvents, heated alkaline detergent wash.

PACKAGING

5 gallon pails and 55 gallon non-returnable drums. Keep container closed during storage to prevent solvent loss.

Before Using This Product – Please Read, Understand and Follow all the Precautions shown on the Product Label and on the Safety Data Sheet.

The Safety Data Sheet can be found on our website:

<https://www.birchwoodtechnologies.com/Downloads/Safety.html>

Use Appropriate Warning Labels on any Container used to Store or Apply this Product.

NOTE: The information contained herein is provided in good faith and is believed to be correct as of the date below. However, Birchwood Laboratories LLC makes no representation as to the comprehensiveness or accuracy of the information. It is expected that individuals receiving the information will exercise their independent judgment in determining its appropriateness for a particular purpose. Accordingly, Birchwood Laboratories LLC will not be responsible for damages of any kind resulting from the use of or reliance upon such information.

DRI-TOUCH™ RPL Replenisher
© Birchwood Laboratories LLC
01/2019

(Product Numbers 811851, 811858)